

Version 0.92

- Added FLARM traffic button
- Added RPM difference nav box
- Added LOP nav box
- Added Hobbs into IGC, Statistics and Flight viewer
- Added FuelManagement from Ebox
- Added Trig Radio TY96 support
- Added new sounds
- Implemented weather (on Side view FPL)
- Receiving Hobbs from RPMflap controller
- Automatic upload of the flights
- Engine warnings
- EBOX notifications
- Fuel level logging
- OBS and HSI improvements
- Flap gauge indicates flap position
- Updated CDI symbol
- Radio menu
- More intuitive editing FPL (on map)
- Trim indicator – fixes
- Fixes for flight statistics in case of lose the power
- Fixed XPDR and RADIO dialogues

Version 0.90

- Supported new types of the sensors (eBox)
- implemented LXNAV connect
- improved terrain warnings
- flarm update via ecopilot
- Improved speed and altitude tape, HSI
- Improved statistic page
- new logbook preview with block time
- traffic displaying on the secondary unit
- new sounds and sound fixes
- bug fixes

Version 0.87

- new supported devices and engine sensors
- minor fixes

Version 0.86

- added new sensors for EBOX
- minor fixes

Version 0.85

- added engine ambient temperature
- added battery temperature
- added engine starter pressure
- increased each fuel tank to 150l, before 100l
- increased number of CHT from 6 to 9
- fix on flight viewer

Version 0.83

- Updated visual style for message dialogs and touch keyboard
- Open logbook flights in Flight Viewer
- Rain radar service updates, it now covers more area