

**Version 3.26**

- improved battery management
- improved WiFi functionality
- minor bug fixes

**Version 3.23**

- added airport frequency information
- added Google drive, DropBox, SeeYou cloud
- added Spanish translation
- improved WiFi communication
- minor GUI fixes – progress bar, added more services icons etc.
- minor other fixes and stability improvements

**Version 3.00**

- Year 2020 fix for nanoconfig app.

**Version 2.40**

- Added flight time in logbook menu
- Fix compression error while sending flight over wi-fi
- Fix device power on issue when battery drained
- Minor bug fixes

**Version 2.32**

- Fixed a bug where device would power off when charging empty battery
- Added device overheating prevention
- German translation fix (“Vertical & horizontal puffer”)

**Version 2.30**

- Added AAT
- Added FAI and task optimization
- Added task management (Save, Load, Export)
- Added translations (German, Italian, French, Slovene, Czech)
- Updated keyboard input with extra symbols
- Added new navboxes
- Added lxn timer connect storage support
- Minor improvements and bugfixes

**Version 2.29**

- multiple languages for user interface

**Version 2.21**

- Major Graphic improvements (Top row, icons, symbols...)
- Added navbox row slider (now you can have 12 navboxes for each page)
- Added many new polars and navboxes
- Added Landing Gear Warning
- Added Airspace Warnings
- Task export / load /edit
- Added Thermal Assistant
- Added glider path

- Multiple .CUP files support
- Flarm symbols improved
- Wind editing on the screen
- Nearest list – improved by icons, arrival altitude added
- Improved airspace display
- Minor bug fixes

#### **Version 1.17**

- minor fix

#### **Version 1.16**

- Fixed transferring bigger files via BT (NanoConfig)
- Fixed some issues with larger waypoint files
- New icons for flarm view

#### **Version 1.15**

- Fixed bug for charging backup battery
- Optimization for opening big CUP files with comments
- Minor fixes and improvements

#### **Version 1.13**

- Enter "zone edit" in task setup on direct press on zone icon.
- Pressure offset instead of altitude offset in alt calculation
- Clearing currently loaded waypoints when loading new cup file.

#### **Version 1.00**

- Initial release.